



ELLSWORTH

A John M. Ellsworth Company

John M. Ellsworth Co., Inc.

P.O. Box 240072
8700 West Bradley Road
Milwaukee, WI 53224

800-333-3331 **PHONE**

info@jmesales.com **E-MAIL**
www.JMESales.com **WEB**

Refueling Tank Installation Instructions

Required Hardware: 3/8 x 1 1/2-16 bolt = 1 per mounting tab
3/8-16 nut = 1 per mounting tab
3/8 flat washer = 2 per mounting tab
3/8 lock washer = 1 per mounting tab

Place the Refueling Tank in the desired location. If you are installing a combo make sure the lid clears the bed when the toolbox lid is in the open position. Mark a location to drill a 3/8" hole in each of the mounting tabs. Before drilling check to make sure you will not drill into hoses, brake lines, wiring, etc. Drill holes thru mounting tabs and truck bed and fit with 3/8"x1 1/2" bolts, flat washer on each side, lock washer and nut. Tighten securely.

***Pump Installation** - Pumps with aluminum threads must be coated with Anti-Seize before installing or threading into the aluminum threads on the tank.

****TTR65FCB** has only two mounting tabs on the bottom of the tailgate side of the tank. This tank must be secured to the floor using both mounting tabs and it must also be secured to the top of the bed up against the bulkhead. Measure height of bed and drill hole through rear of toolbox so that it can be secured to bed. Make sure to use flat washers on front and back of toolbox.