



Part No. JDI-436ZB & Part No. JDI-636ZB

READ AND SAVE THIS MANUAL

CONTENTS:

- 1 ZIP-BOOT
- 2 Clamps
- 1 Adhesive Package

ASSEMBLY INSTRUCTIONS:

- 1. Install the ZIP-BOOT around the flexible connection. Insert the right-handed side of the track into the lower half of the locking mechanism, then close the zipper on the ZIP-BOOT.
- Apply a film of adhesive between the fitting and the ZIP-BOOT, then clamp the ZIP-BOOT over the piping and tighten securely.

FOR SERVICE ASSISTANCE, CALL 800-433-0708 OR VISIT JOHNDOW.COM





151 Snyder Ave. Barberton, OH 44203