

Air Valve Upgrade Kit

406933B

EN

Kit 24K224

For Graco Air Valve Models 24B766, 24B773, 24B775, and 24C826



Important Safety Instructions

Read all warnings and instructions in this manual and in your air motor or pump manual. Save all instructions.


Parts

Standard air valves - for systems with no Data-Trak or with DataTrak with Cycle Count Only

Ref.	Description	Qty
1	CAP, air valve	2
2	O-RING, Buna-n, ID 1.0 in. (25.4 mm)	2
3	O-RING, FKM, ID 0.9 in. (23 mm)	2
4	SNAP RING	2

NOTE: The o-rings are different in size. Stack on bench to differentiate.

NOTE: A small amount of air will exhaust during stall if the pump is stopped while in the process of changing over. This is normal. If desired, Valve Upgrade Kit 24K224 can be installed to minimize air exhausting.



△ Apply lubricant.

ti17484a

Graco Inc. P.O. Box 1441 Minneapolis, MN 55440-1441

406933 Original instructions. This manual contains English.

Copyright 2011, Graco Inc. is registered to ISO 9001