

Models - 9420\* & 9420-1\* Coin Operated Models

9420-1C\* Commercial Models

9420CGDH



Page 2 Product Information

Page 3 Specifications

Page 4 Important Safety Instructions

Page 5-7 Product Dimensions

Page 8-13 Installation

Page 13-14 Programming

Page 15 Operating Instructions

Page 15-16 Maintenance & Troubleshooting

Page 17-24 Parts List

Page 25-27 Wiring Diagram



# **PRODUCT INFORMATION**

Please take a moment to fill out the information below in order to aid us with any future sales or service inquiries. Model number and serial number information can be found on the serial tag located inside the control box and/or on the lower exterior of the can. Key number can be found on the tag that comes attached to the keys. There may be more than one key number depending on unit.

Please keep this information with your records.

MODEL#:	
SERIAL#:	
KEY NUMBER(S):	
DATE PURCHASED:	
DISTRIBUTOR:	

J.E. Adams Industries 1025 63rd Ave. S.W. Cedar Rapids, IA 52404 1-800-553-8861

www.jeadams.com

## **Specifications**

Unit specifications: Gast twin cylinder compressor models

Voltage: 120VAC, 60Hz

Amperage: (1) 10 & (1) 20 amp services are required for this unit (both air and vac may run/vend at the same time)

Weight: 180-190 lbs with pallet

Vac Motor: (2) 120VAC vacuum motor (requires dedicated 20A service)

Fuses: (2) 10 amp inline fuses (vac motors)

Compressor: Gast 3/4 HP, 120VAC, 60HZ (requires dedicated 10A service)

Unit specifications: 9420CGDH (ONLY)

Voltage: 120VAC, 60Hz

Amperage: (1) 30 amp service is required.

Weight: 195-205 lbs with pallet Vac Motor: (3) 120VAC vacuum motor

Fuses: (3) 10 amp inline fuses (vac motors)

Compressor: Gast 3/4 HP, 120VAC, 60HZ

Gast compressor



Duty cycle time 4 minutes on, 4 minutes off.

### NOTE: "UNIT INTENDED FOR COMMERCIAL USE ONLY"

### IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:

### READ ALL INSTRUCTIONS BEFORE USING (THIS APPLIANCE)

### **WARNING** – To reduce the risk of fire, electric shock, or injury:






- Do not use on wet surfaces.
- Use only as described in manual. Use only manufactures recommended attachments.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without dust bag and/or filters in place.


#### SAVE THESE INSTRUCTIONS

- Installation Instructions:
- Determine location to mount unit ("DANGER" "THIS EQUIPMENT INCORPORATES PARTS SUCH AS SWITCHES, MOTORS, OR THE LIKE THAT TEND TO PRODUCE ARCS OR SPARKS THAT CAN CAUSE AN EXPLOSION. WHEN LOCATED IN GASOLINE-DISPENSING AND SERVICE STATIONS INSTALL AND USE AT LEAST 20 FEET (6 M) HORIZONTALLY FROM THE EXTERIOR ENCLOSURE OF ANY DISPENSING PUMP AND AT LEAST 18 INCHES (450 MM) ABOVE A DRIVEWAY OR GROUND LEVEL."
- Run electrical service to that location.
- **Grounding Instructions**: This appliance must be connected to a grounded metal, permanent wiring system; or an equipment-grounding conductor must be run with the circuit conductors and connected to the equipment-grounding terminal or lead on the appliance.
- All local and national electric codes must be followed for installation and use.
- Licensed electricians are recommended for installation.


# **Product Dimensions**





# **Product Dimensions**





# **Product Dimensions**
















To attach hose, thread into metal hole counter clockwise.

Once unit has been installed use 5871B8 cap plugs (supplied with unit) to seal holes in canister bottom located in lower cleanout door. Extra cap plugs are included with the unit in case plug becomes damaged during shipping removal.





Edge of hose will need to start here.

#### place using index finger and thumb. With edges of plug resting against edges of hole, firmly push down on plug with end of hammer or other blunt object until plug

plugs into bottom holes,

pinch cap plug into

snaps into place.


### **Programming Instructions:**

### Coin acceptor:

No programming to acceptor needed if unit was purchased with the standard Imonex Z3 acceptor (8149 JEA part number) as it is built accept US quarters. If different acceptor was purchased, see additional literature sent along with unit for programming info.

### **Programming:**

The below timer pictured is the standard SSAC model that allows the end user to select the "coins to start" and the "total time" by settings series of dip switches. The number of "coins to start" dip switch is how many quarters are needed to make the machine come on. In the below example, the "one coin" dip is selected which makes the unit come on with one coin. The "total time" will then need to be set, but a good rule of thumb would be 4 minutes which requires dip switches 3.2 and .8 to be set to on. This scenario means 1 quarter will provide 4 minutes of vacuum time. The total time can always be changed by adding or subtracting time. If the operator would later decide to increase the cost of the unit to "2" quarters, the 2 dip switch would need to be in the on position (all others off) and the time dip switches would still be 3.2 and .8 dips selected for 4 minutes. Timer is non-accumulating so "coins to start" setting is just to make the machine turn on and "time" is total time regardless of coins to start setting.



### **Operating Instructions:**

- Insert payment (coins) to start vacuum or air compressor.
- Once service is used, hang up hose.

#### **Maintenance:**

- All servicing of machine should be conducted by an authorized service representative!
- Filter bags should be accessed and shaken down weekly. It is recommended to keep a new set of bags on hand so that once every few months the bags can be replaced and then laundered.
- To maintain performance, empty dirt bin from the canister on a regular basis.
- Periodically inspect wires and connections for wear or fatigue.
- Check door and motor gaskets periodically for signs of wear or damage and replace as needed.
- Check vac hose, air hose, and air chuck/gasket for cracks or damage on a weekly basis.
- Clean canister with a stainless steel cleaner as needed. Decals can be cleaned with mild soap and water.
- Check motor brushes every month for excessive wear. Motor brushes should be changed immediately if they are 1/4" or shorter. *Please disconnect power before doing this!*





#### DISCONNECT POWER BEFORE SERVICING OR TROUBLESHOOTING!







### **Troubleshooting:**


Problem	Possible cause	Solution
Unit is not powered.	Breaker inside unit is not in the on position.	Flip breaker on.
·	No power to machine.	Check incoming power.
	Loose connection.	Check incoming power connection.
Machine is behaving erratically.	Is the incoming power at 120V?	Check voltage and monitor while machine runs. Low voltage can cause erratic behavior.
	Are any of the machines wires worn through or connections not making contact?	Inspect wiring and connections. Look for sharp bends in wires and places where wire is against the metal chassis.
Unit keeps tripping breaker.	Inadequate wire size ran to machine.	Call electrician and install proper wire size for 20amp service versus length or run.
	Wrong size breaker.	Install correct breaker (only if wire size is adequate to handle 20 amp breaker).

	Inadequate wire size ran to machine.	Call electrician and install proper wire size for		
blowing.		20amp service versus length or run.		
	Motor brushes may be bad or too short.	Replace motor brushes.		
Lack of vacuum suction.	Vac hose clogged?	Clean debris from vac hose.		
	Filter bags need cleaned or dirt chamber needs emptied?	Shake or clean filter bags or replace and empty		
		lower dirt chamber.		
	Vac hose is split?	Replace/repair vac hose.		
	Cleanout door gaskets torn or worn?	Replace gaskets.		
	Vac motor gaskets are worn or motor is not tight against.	Inspect/replace gaskets and assure motor is		
		tight against them.		
	Lower chamber cap plugs/mounting hole covers have	Open lower chamber and inspect plugs, order		
	popped out?	new if needed.		
	Cleanout door gaskets torn or worn?	Replace gaskets.		
	One of the vac motors is not working?	Check line motor fuse and replace. Replace		
		motor if necessary.		
	Air is leaking from unit somewhere.	Turn power off to unit, apply chuck to air		
		source with at least 30lbs of pressure and listen		
		carefully for leaks inside cabinet or air hose.		
		Replace faulty component if leaking.		
	If no system leaks, is compressor putting out enough	If compressor cannot force air into tire, the		
Compressor runs but will	pressure?	compressor may have exceeded its life span		
not inflate tire.		and need rebuilt (about 1000 hours).		
not innate the.	Chuck washer is worn out?	Replace rubber washer inside chuck with JE		
		Adams PN 8533-3CW.		
	Temperature is below freezing and condensation off	Remove air hose and chuck and bring into		
	compressor has froze in air hose.	warm area to thaw. Optional air dry systems		
		are available through JE Adams if frequent		
		problem- please call.		





		BILL OF MATERIALS				BILL OF MATERIALS	
ITEM	PART NUMBER		QTY	ITEM	PART NUMBER	DESCRIPTION	QTY
34	8183	DECAL, WARNING	3	1	2036	HOSE, 2" X 15' BLACK VACUUM	1
35	8305	ASSEMBLED SS DOME	1	2	2058	CLAW/CUFF ASSEMBLY, 2"	1
36	8427-1	DECAL, VACUUM	1	3	5600D4	3/8-16 X 1.5 HHCS	4
37	8427-2	DECAL, AIR	1	4	5601D4	1/4-20 x 3/4 HHCS-SS	1
38	8427-3	DECAL, DOME	1	5	5603D1	10 Std NC Nylock Nut	3
39	8429-1	DECAL, HANG HOSE	1	6	5603D11	1/2 Std NC Nylock Nut	1
40	8450	DECAL, TOP HEAVY	1	7	5603D2	1/4 Std NC Nylock Nut	1
41	8532-25	AIR HOSE ASSY, 1/4" X 25'	1	8	5603D5	1/4 Std NC Nylock Nut	4
42	8533-8	TIRE INFLATOR W/ GAUGE	1	9	5606D21	WASHER, FLAT, 3/4 SAE, ID 13/16	1
43	8549	FLEX STRAIN RELIEF	1	10	5606D22	WASHER, 3/8 FENDER	8
44	8605	PALLET, VAC, 26" X 30.5"	1		5606D7	FLAT WASHER, .160 ID X .500 OD	1
45	8609RW	FACEPLATE W/C, DUAL ACCEPTORS	1	12	5627D2	Pan Head, Slotted, 6-32 x 5/8	1
46	8615-5W	CLEANOUT DOOR WELDMENT	2	20.750	5639D4	RUBBER GROMMET	1
47	8638	PIN LOCK	1		5647D2	1/8" SS POP RIVET	16
48	8646A	TIMER ASSEMBLY, AIR/VAC	1		5647D8	3/16" SS POP RIVET	14
49	8673-11	GROUND WIRE 28"	1	16	5684D2	1/2" DIA. HOSE CLAMP	1
50	8732	NAMEPLATE, PRODUCT SPEC'S	1		5800D6	90 DEG. NPT STREET ELBOW	1
51	8754	WARNING DECAL	1		5871b8	PLUG, VAC BOTTOM 2-1/2"	8
52	8920-71	BOX	1		6082	BAG, 9 X 12	1
53	9420FPD	DECAL, FACEPLATE	1		8047	BAG, 60 X 72	1
54	9423W	CANISTER WELDMENT, AIR/VAC, VR	1		8051G	BRACKET, MOTOR MOUNT	1
55	9862	110VAC 3/4 TWIN GAST COMPRESSOR	1		8055EM	MOTOR, ELECTRO 120V	2
56	B5722-002	NUT, 3/8-16 UNC HEX LOCK NUT	4	7.000.000		WIRE LEAD, EM VAC MOTOR	4
57	8437D001	ETL LISTED LABEL	1		8057	MOTOR GASKET	2
				1.7	8076	FILTER BAG	4
					8081	CABLE TIE MOUNT	2
		PUF			8084	CABLE TIE	3
				S	8085	15" CABLE TIE	2
					8108	#10 x 1/2 TAP SCREW	4
					8149	IMONEX COIN ACCEPTOR	2
			110		8153-1	LATCH, CLEANOUT DOOR	4
			,		8157	NUT, #6-32 KEPP NUT STAINLESS	9
				33	8159	DOOR GASKET	2
					TITLE	AIR/VAC, 2DR, VR	
В	6961	ADDED 8437D001		5-22-12	CK UNSPECIFIE		DS, IOW
Α	6467 REVISI	ED AND DRAWN TO INVENTOR; NO PREVIOUS DRA	AWING	4-22-11		SCALE	VICE
REV	NO.	DESCRIPTION		DATE	BY 2 PL ±.01	DRAWN BY CHAD K.	LT



PART		
NO.	9420-	1006
	34/11-	1 ( ) ( ) 1

98

99

6025SHR

8646-C


REEL CRAFT, BASE MOUNT

CONTROL ASSEMBLY, COMMERCIAL AIR/VAC

		BILL OF MATERIALS				BILL OF MATERIALS	
ITEM	PART NUMBER	DESCRIPTION	QTY	ITEM	PART NUMBER	DESCRIPTION	QTY
36	8081	CABLE TIE MOUNT	2	1	2036	HOSE, 2" X 15' BLACK VACUUM	1
37	8084	CABLE TIE	3	2	2058	CLAW/CUFF ASSEMBLY, 2"	1
38	8085	15" CABLE TIE	2	3	3054	1/4" HOSE BARB X 1/" MPT	1
39	8108	#10 x 1/2 TAP SCREW	4	4	5035D3	DOWEL PIN	4
40	8153-1	LATCH, CLEANOUT DOOR	4	6	5600D4	3/8-16 X 1.5 HHCS	4
41	8157	NUT, #6-32 KEPP NUT STAINLESS	1	7	5603D1	10 Std NC Nylock Nut	2
42	8159	DOOR GASKET	2	8	5603D11	1/2 Std NC Nylock Nut	1
43	8183	DECAL, WARNING	3	9	5603D5	1/4 Std NC Nylock Nut	8
44	8305	ASSEMBLED SS DOME	1	10	5606D22	WASHER, 3/8 FENDER	8
45	8427-1	DECAL, VACUUM	1	11	5606D7	FLAT WASHER, .160 ID X .500 OD	1
46	8427-2	DECAL, AIR	1	12	5611D4	NUT, 5/16-18 UNC KEPP- SS	2
47	8427-3	DECAL, DOME	1	13	5627D2	6-32 x .63 PD, PH, MS	1
48	8429-1	DECAL, HANG HOSE	1	14	5635D4	1/4-20 UNC CARRIAGE BOLT	4
49	8450	DECAL, TOP HEAVY	1	15	5636D1	#10-24 PHIL, PAN HEAD SCREW	2
50	8505-1C	COVER, CONTROL PLATE, AIR/VAC COMMERCIAL	1	17	5639D4	RUBBER GROMMET	1
51	8533-8	TIRE INFLATOR W/ GAUGE	1	18	5643D2	SS HOSE CLAMP, 7/16-25/32"	1
52	8549	FLEX STRAIN RELIEF	1	19	5647D2	1/8" SS POP RIVET	16
53	8588BY	DECAL, FREE AIR	1	20	5647D8	3/16" SS POP RIVET	14
54	8589BY	DECAL, FREE VAC	1	21	5871b8	PLUG, VAC BOTTOM 2-1/2"	8
58	8615-5W	CLEANOUT DOOR WELDMENT	2	26	6027-1	RETAINER, ROLLER	1
59	8630	TUBE, 30.5 X 26 X 60	1	27	6027-2	COVER, HOSE GUIDE	2
61	8673-11	GROUND WIRE 28"	1	28	6027-3	ROLLER, HOSE GUIDE	4
62	8732	NAMEPLATE, PRODUCT SPEC'S	1	29	6082	BAG, 9 X 12	1
63	8754	WARNING DECAL	1	30	8047	BAG, 60 X 72	1
66	8939	PALLET, DUAL, OVAL, SPECIALITY, 30" X 40"	1	31	8051G	BRACKET, MOTOR MOUNT	1
67	9421W2-1C-RC	AIR/VAC CANISTER W/C, COMMERCIAL, REEL CRAFT	1	32	8055EM	MOTOR, ELECTRO 120V	2
68	9850-430	30" HOSE	1	34	8057	MOTOR GASKET	2
69	9862	110VAC 3/4 TWIN GAST COMPRESSOR	1	35	8076	FILTER BAG	4
70	B5722-002	NUT, 3/8-16 UNC HEX LOCK NUT	4				
71	8437D001	ETL LISTED LABEL	1				
				4			



E	7731	ADDED AND REMOVED PARTS, SEE ECR FOR LIST	4-5-16	CK			
D	7097	REMOVED 9421W2-1C, 6025-26W-1, 5600D2 (6), 8597 (4), 8598 (4) 8596 (4) & COX REEL. ADDED 9421W2-1C-RC & REEL CRAFT	4-30-13	СК	TITLE		
С	6961	ADDED 8437D001	2-22-12	CK	A	IR/VAC, 2DR, HOSE	E REEL, COMMERCIAL
В	6956	ADDED (2) EA 5627D2 & 8157 & (1) 5903D1	5-11-12	СК	UNSPECIFIED TOLERANCES	MATERIAL	CEDAR RAPIDS, IOWA
Α	6465	REVISED AND DRAWN TO INVENTOR; NO PREVIOUS DRAWING	4-21-11	СК	1 PL ±.030	SCALE	
REV	NO.	DESCRIPTION	DATE	BY	2 PL ±.010	DRAWN CHAD K.	CONTROL OF THE SAMES
		UMENT SHALL NOT BE REPRODUCED NOR SHALL THE INFORMATION THER OR DISCLOSED TO OTHERS EXCEPT AS AUTHORIZED BY J.E. ADAMS INDUS			3 PL ±.003 ANGLE ±1.0	DATE 4/21/2011	PART 9420-1CGH E



31 32		BILL OF MATERIALS				BILL OF MATERIALS		
	PART NUMBER	DESCRIPTION	QTY	ITEM	PART NUMBER	DESCRIPTION	Q	
32	8505-1C	COVER, CONTROL PLATE, AIR/VAC COMMERCIAL	1	1	2036	HOSE, 2" X 15' BLACK VACUUM		
	8532-25	AIR HOSE ASSY, 1/4" X 25"	1	2	2058	CLAW/CUFF ASSEMBLY, 2"		
33	8533-8	TIRE INFLATOR W/ GAUGE	1	3	2058-13W	CLAW HANGER, 1.5-2" UNIVERSAL WMT		
34	8549	FLEX STRAIN RELIEF	1	4	2058-14	PLATE, RUBBER SUPPORT, VAC		
35	8588VA-BY	DECAL, FREE, ON/OFF, AIR/VAC	1	5	2058-3	RUBBER PAD, HOSE HANGER		
36	8615-5W	CLEANOUT DOOR WELDMENT	2	6	28000-36	MOTOR MOUNT		
37	8631	PAD, 11 X 55	1	7	5600D4	BOLT, HHCS 3/8-16 X 1-1/2"		
38	8673-10-4	WIRE ASSEMBLY, 3 MOTOR AIR VAC	1	8	5601D13	SCR,1/4-20x1/2 PPHSqConeStepZP		
39	8673-11	GROUND WIRE 28"	1	9	5601D4	1/4-20 x 3/4 HHCS-SS		
40	8732	NAMEPLATE SERIAL TAG, UL	1	10	5603D2	1/4 Std NC Nylock Nut SS		
41	8754	DECAL- ENGLISH/FRENCH/SPANISH, WARN	1	11	5606D21	WASHER, FLAT, 3/4 SAE, ID 13/16		
42	8939	PALLET	1	12	5606D22	WASHER, FENDER 3/8"		
43	9236-3W-DH-3	3 MOTOR, AIR VAC CANISTER	1	13	5611D2	NUT, 10-24 UNC KEPP- ZINC	T	
44	9862	COMPRESSOR, 3/4 HP TWIN CYL	1	14	5627D2	6-32 x .63 PD, PH, MS		
45	B5722-022	NUT, HEX LOCK, 3/8"	4	15	5636D1	10-24 PHIL. PAN HEAD SCREW		
TE 1				16	5647D2	RIVET, 1/8 SS POP		
		R AIR VACUUM TO WIRE UNIT.		17	5647D8	RIVET, 3/16" SS POP		
E LENGTH	HS ARE CALLE	D OUT ON 8673-10-4.		18	5684D2	1/2" DIA. HOSE CLAMP		
				19	5800D6	90 DEG. NPT STREET ELBOW		
	1			20	5871b8	PLUG, VAC BOTTOM 2-1/2"		
				21	8055EM	MOTOR, ELECTRO 120V		
				22	8057	MOTOR GASKET		
	4			23	8076	FILTER BAG		
				24	8108	#10 x 1/2 TAP SCREW		
				25	8153-1	LATCH, CLEANOUT DOOR		
				26	8159	DOOR GASKET		
				27	8183	DECAL, "DISCONNECT POWER"		
		Y Cal		28	8305	ASSEMBLED SS DOME		
		H H		29	8427-1	DECAL, VACCUM		
				30	8427-2	DECAL, AIR		

