

## Gravity Fuel Tank Installation Instructions:

**Note: Make sure to use fuel compatible pipe dope or thread tape on all threaded connections**

- Install riser pipe in 2 in. bung opening on top of the tank opposite of the ¾ in. dispense outlet
- Install the vent on top of the riser pipe
- Install the tank gauge into the 2 in. bung hole on top of the tank on same side as ¾ in. dispense outlet
- Install the fill cap into the middle 2 in. bung hole

### Dispense Kit Installation:

- Install 1 of the ¾ in. pipe nipples into the tank outlet
- Install the locking ball valve onto the pipe nipple making sure the handle is facing away from the tank when open
- Install the 2<sup>nd</sup> pipe nipple into the ball valve.
- Install the filters IN port to the pipe nipple.
- Install the 45° street elbow into the OUT port of the filter making sure it points toward the ground.
- Install the 12 ft hose into the Street elbow.
- Install the dispensing nozzle onto the hose.

