


GRAVITY FEED TANK ON STAND

NOTE:

IT IS HIGHLY RECOMMENDED THAT YOU DO NOT TIGHTEN THE BOLTS UNTIL FULLY ASSEMBLED, BUT PRIOR TO SETTING THE TANK ON TOP.



PART NO.	QTY.	PART NAME	SIZE
1	4	LEG	2 X 2 ANGLE 84" LONG
2	2	LOWER END BRACE	2 X 2 ANGLE 45 1/2" LONG
3	4	SIDE BRACE	1 1/4 X 1 1/4 ANGLE 64 5/8" LONG
4	4	END BRACE	1 1/4 X 1 1/4 ANGLE 31 3/4" LONG
5	4	LOWER BRACE	2 X 2 ANGLE 56 1/4" LONG
6	2	TOP BRACKET	2 1/4 X 2 1/4 ANGLE 60" LONG
7	34	BOLT - HEX HEAD W/NUT	3/8 - 16 X 3/4" LONG



John M. Ellsworth Co., Inc.

P.O. Box 240072
8700 West Bradley Road
Milwaukee, WI 53224

800-333-3331 PHONE
info@jmesales.com E-MAIL
www.JMESales.com WEB