



ULTRATECH
INTERNATIONAL, INC.

Ultra-Pellet Pond®

Instructions

1. After unboxing the Ultra-Pellet Pond® and four included piece of rebar, unfold and inspect the material for any rips, tears or damage. Please contact UltraTech customer service at 904.292.1611 if any issues are found.
2. Flip the pond over so the bottom is facing up.
3. Insert one piece of rebar into each sleeve heat-sealed into the bottom of the pond.
4. Insure that the flap at the end of each sleeve is pulled out so the rebar is “locked” into place and won’t slide out when the Ultra-Pellet Pond is being moved around.
5. Flip the pond back - right side up.
6. Your Ultra-Pellet Pond® is now ready for use.



NOTE: Pellets should be removed periodically, especially from around/on the drain to reduce the chance of flooding.



John M. Ellsworth Co., Inc.

A John M. Ellsworth Company

P.O. Box 240072
8700 West Bradley Road
Milwaukee, WI 53224

800-333-3331 **PHONE**

info@jmesales.com **E-MAIL**
www.JMESales.com **WEB**