Dixon® Fire Spec Sheet
Storz Measurement Guide

DIXON
The Right Connection®



- Heads are marked with inch and or metric Storz size
- If heads are unmarked, measure lug spacing and compare

Storz Description	Inside Distance Between Lugs
1" or 25 mm	1-7/32" or 31 mm
1-1/2" or 38 mm	2-1/16" or 52 mm
2" or 50 mm	2-5/8" or 66 mm
2-1/2" or 65 mm	3-3/16" or 81 mm
3" or 75 mm	3-1/2" or 89 mm
4" or 100 mm	4-1/2" or 115 mm
5" or 125 mm	5-13/16" or 148 mm
6" or 150 mm	3 lugs or 160 mm

JME® ELLSWORTH
A John M. Ellsworth Company
John M. Ellsworth Co., Inc.

P.O. Box 240072
8700 West Bradley Road
Milwaukee, WI 53224

800·333·3331 **PHONE**

info@jmesales.com **E-MAIL**
www.JMEsales.com **WEB**