

FREQUENTLY ASKED QUESTIONS

- **Q** Does the **AQUAsonic** Saddle read through the pipe?
- A No, a hole is drilled into the pipe, so the **AQUAsonic** insert can extend into the fluid.
- **Q** Can the **AQUAsonic** accurately read any type of fluid?
- A No, it is for water applications ONLY.
- **Q** Can the **AQUAsonic** meter be damaged by debris or air?
- A No, the **AQUAsonic** meter has no moving parts that can be damaged.
- **Q** How long will the battery last in the **AQUAsonic** meter?
- A Two years, average
- **Q** Can I get a pulse output or a 4-20 mA output from the **AQUAsonic** meter?

Not from the Battery-Powered model, but we will be releasing the next
A version of the AQUAsonic meter very soon that will be able to supply both outputs.

Q Why does the **AQUAsonic** meter need to be installed at an angle?

Air will block an ultrasonic signal. If air is present in the line, it will travel
along the top of the pipe. When the AQUAsonic is installed at an angle, this keeps the air away from the transducers, so the signal is not blocked.

Q Am I required to have straight pipe installed both in front and behind the **AQUAsonic** meter?

Yes, you want to take the diameter of the meter 10X on the inlet and 5X on the outlet. For a 1-inch meter this would be 10-inches of straight 1-inch pipe going in and 5-inches of straight 1-inch pipe coming out. If you cannot do this you can still install the meter but the accuracy will be affected.





FAQS CONTINUED

Q Why do you have PVC tees for the smaller sizes and saddles for the larger sizes?

A This is the most economical way to offer the AQUAsonic meter. PVC tees are not too expensive for smaller pipe sizes but can be very expensing once the pipe size gets over 4-inch. What is more, installing a larger PVC tee is a particularly challenging process.

- **Q** Can the **AQUAsonic** meter be out in the elements?
- A Yes, it has an **IP67** rating. This means it is dust tight and is protected against immersion in 1 meter of water for 30 minutes.
- **Q** What is Ultrasonic Transit Time technology?

Ultrasonic flow meters are based on the principle that the time an acoustic signal takes to travel a known path is altered by the fluid velocity. The

- A acoustic signal sent upstream travels slower than a signal sent downstream. A comparison is made of upstream and downstream time measurements to determine the fluids velocity.
- **Q** Does the **AQUAsonic** meter give you both totals and rate of flow?

The AQUAsonic meter will provide Accumulative Total, a Resettable Batch
A Total, and Rate of Flow. You can switch between these different options with a simple push of a button.

Q My **AQUAsonic** display reads in Gallons. Can I change it to read in Liters?

Yes, the display can easily be changed in the field by the user to Gallons,
Imperial Gallons, Acre-Foot, Quart, Ounce, Liter, Millilitre, Cubic Metre, Cubic Centimetre, Cubic Foot, Barrel, or Custom (set by user).



© 2023 Great Plains Industries, Inc. All Rights Reserved.

Service & Warranty: For technical assistance, warranty replacement or repair contact your FLOMEC® or GPI® distributor: In North or South America: 888-996-3837 / greatplainsindustries.com Outside North or South America: +61 2 9540 4433 / FLOMEC.com.au